







| Symbol Key  |                    |
|---|--------------------|
|  | Par64              |
|  | Strand Quartet F   |
|  | Acclaim Fresnel    |
|  | SL23-50            |
|  | Intimidator 355z   |
|  | SlimPar Quad 6 IRC |

Drama Barn House Plot  
 The Drama Barn  
 University Of York

Revision 1.0  
 Drawn By John Cherry  
 April 2021

PLOT

|                     |         |            |                   |       |               |                  |  |
|---------------------|---------|------------|-------------------|-------|---------------|------------------|--|
| <b>Channel: 5</b>   |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
|                     | 5       | SL23-50    | Auditorium Circle |       | Stage Left    | Conventionals,   |  |
| <b>Channel: 6</b>   |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
|                     | 6       | SL23-50    |                   |       | Stage Right   | Conventionals,   |  |
| <b>Channel: 7</b>   |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0350              | 7       | Selecon    | LX1               |       | Up Left       | Conventionals,   |  |
| <b>Channel: 8</b>   |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0340              | 8       | par64mfl   | LX1               |       | Stage Right   | Conventionals,   |  |
| <b>Channel: 9</b>   |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0351              | 9       | Selecon    | LX1               |       | Down Right    | Conventionals,   |  |
| <b>Channel: 10</b>  |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0352              | 10      | Selecon    | LX1               |       | Down Left     | Conventionals,   |  |
| <b>Channel: 11</b>  |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0341              | 11      | par64mfl   | LX1               |       | Stage Left    | Conventionals,   |  |
| <b>Channel: 12</b>  |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0353              | 12      | Selecon    | LX1               |       | Up Right      | Conventionals,   |  |
| <b>Channel: 13</b>  |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0342              | 13      | Strand     | SR Low            |       | Stage Left    | Conventionals,   |  |
| <b>Channel: 14</b>  |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0343              | 14      | Strand     | SR Low            |       | Downstage     | Conventionals,   |  |
| <b>Channel: 15</b>  |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0344              | 15      | Strand     | SR Low            |       | Up Left       | Conventionals,   |  |
| <b>Channel: 16</b>  |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0345              | 16      | Strand     | SR Low            |       | Up Left       | Conventionals,   |  |
| <b>Channel: 21</b>  |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0334              | 21      | par64mfl   | SR Powered Bar    |       | Under Balcony | Conventionals,   |  |
| <b>Channel: 27</b>  |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0338              | 27      | par64mfl   | SL Powered Bar    |       | Under Balcony | Conventionals,   |  |
| <b>Channel: 31</b>  |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0346              | 31      | Strand     | SL Low            |       | Stage Right   | Conventionals,   |  |
| <b>Channel: 32</b>  |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0347              | 32      | Strand     | SL Low            |       | Downstage     | Conventionals,   |  |
| <b>Channel: 33</b>  |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0348              | 33      | Strand     | SL Low            |       | Up Right      | Conventionals,   |  |
| <b>Channel: 34</b>  |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0349              | 34      | Strand     | SL Low            |       | Up Right      | Conventionals,   |  |
| <b>Channel: 41</b>  |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
|                     | 41      | SL23-50    | LX2               |       | Foleage Gobo  | Conventionals,   |  |
| <b>Channel: 42</b>  |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0354              | 42      | Selecon    | Balcony Bar       |       | Stage Right   | Conventionals,   |  |
| <b>Channel: 43</b>  |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0355              | 43      | Selecon    | Balcony Bar       |       | Center Stage  | Conventionals,   |  |
| <b>Channel: 44</b>  |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0357              | 44      | Selecon    | Balcony Bar       |       | Center Stage  | Conventionals,   |  |
| <b>Channel: 45</b>  |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
|                     | 45      | Selecon    | Balcony Bar       |       | Stage Left    | Conventionals,   |  |
| <b>Channel: 46</b>  |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
|                     | 46      | SL23-50    | LX2               |       | Foleage Gobo  | Conventionals,   |  |
| <b>Channel: 101</b> |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0328              | 129     | Chauvet DJ | LX1               |       |               | All LEDs, Movers |  |
| <b>Channel: 102</b> |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0329              | 144     | Chauvet DJ | LX1               |       |               | All LEDs, Movers |  |
| <b>Channel: 103</b> |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0331              | 159     | Chauvet DJ | LX2               |       |               | All LEDs, Movers |  |
| <b>Channel: 104</b> |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0332              | 174     | Chauvet DJ | LX2               |       |               | All LEDs, Movers |  |
| <b>Channel: 201</b> |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0318              | 49      | Chauvet DJ | LX1               |       | Stage Right   | All LEDs, LEDs   |  |
| <b>Channel: 202</b> |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0319              | 57      | Chauvet DJ | LX1               |       | Center Stage  | All LEDs, LEDs   |  |
| <b>Channel: 203</b> |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0320              | 65      | Chauvet DJ | LX1               |       | Center Stage  | All LEDs, LEDs   |  |
| <b>Channel: 204</b> |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0321              | 73      | Chauvet DJ | LX1               |       | Stage Left    | All LEDs, LEDs   |  |
| <b>Channel: 211</b> |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0322              | 81      | Chauvet DJ | Balcony Bar       |       | Stage Right   | All LEDs, LEDs   |  |
| <b>Channel: 212</b> |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0323              | 89      | Chauvet DJ | Balcony Bar       |       | Center Stage  | All LEDs, LEDs   |  |
| <b>Channel: 213</b> |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0324              | 97      | Chauvet DJ | Balcony Bar       |       | Center Stage  | All LEDs, LEDs   |  |
| <b>Channel: 214</b> |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0325              | 105     | Chauvet DJ | Balcony Bar       |       | Stage Left    | All LEDs, LEDs   |  |
| <b>Channel: 221</b> |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0326              | 113     | Chauvet DJ | SR Under Balcony  |       | Under Balcony | All LEDs, LEDs   |  |
| <b>Channel: 222</b> |         |            |                   |       |               |                  |  |
| #                   | Address | Type       | Position          | Color | Use           | Group            |  |
| A-0327              | 121     | Chauvet DJ | SL Under Balcony  |       | Under Balcony | All LEDs, LEDs   |  |

|              |        |         |            |                   |               |
|--------------|--------|---------|------------|-------------------|---------------|
| Address: 5   | #      | Channel | Type       | Position          | Use           |
|              | 5      | SL23-50 |            | Auditorium Circle | Stage Left    |
| Address: 6   | #      | Channel | Type       | Position          | Use           |
|              | 6      | SL23-50 |            |                   | Stage Right   |
| Address: 7   | #      | Channel | Type       | Position          | Use           |
|              | A-0350 | 7       | Selecon    | LX1               | Up Left       |
| Address: 8   | #      | Channel | Type       | Position          | Use           |
|              | A-0340 | 8       | par64mfl   | LX1               | Stage Right   |
| Address: 9   | #      | Channel | Type       | Position          | Use           |
|              | A-0351 | 9       | Selecon    | LX1               | Down Right    |
| Address: 10  | #      | Channel | Type       | Position          | Use           |
|              | A-0352 | 10      | Selecon    | LX1               | Down Left     |
| Address: 11  | #      | Channel | Type       | Position          | Use           |
|              | A-0341 | 11      | par64mfl   | LX1               | Stage Left    |
| Address: 12  | #      | Channel | Type       | Position          | Use           |
|              | A-0353 | 12      | Selecon    | LX1               | Up Right      |
| Address: 13  | #      | Channel | Type       | Position          | Use           |
|              | A-0342 | 13      | Strand     | SR Low            | Stage Left    |
| Address: 14  | #      | Channel | Type       | Position          | Use           |
|              | A-0343 | 14      | Strand     | SR Low            | Downstage     |
| Address: 15  | #      | Channel | Type       | Position          | Use           |
|              | A-0344 | 15      | Strand     | SR Low            | Up Left       |
| Address: 16  | #      | Channel | Type       | Position          | Use           |
|              | A-0345 | 16      | Strand     | SR Low            | Up Left       |
| Address: 21  | #      | Channel | Type       | Position          | Use           |
|              | A-0334 | 21      | par64mfl   | SR Powered Bar    | Under Balcony |
| Address: 27  | #      | Channel | Type       | Position          | Use           |
|              | A-0338 | 27      | par64mfl   | SL Powered Bar    | Under Balcony |
| Address: 31  | #      | Channel | Type       | Position          | Use           |
|              | A-0346 | 31      | Strand     | SL Low            | Stage Right   |
| Address: 32  | #      | Channel | Type       | Position          | Use           |
|              | A-0347 | 32      | Strand     | SL Low            | Downstage     |
| Address: 33  | #      | Channel | Type       | Position          | Use           |
|              | A-0348 | 33      | Strand     | SL Low            | Up Right      |
| Address: 34  | #      | Channel | Type       | Position          | Use           |
|              | A-0349 | 34      | Strand     | SL Low            | Up Right      |
| Address: 41  | #      | Channel | Type       | Position          | Use           |
|              | 41     | SL23-50 |            | LX2               | Foleage Gobo  |
| Address: 42  | #      | Channel | Type       | Position          | Use           |
|              | A-0354 | 42      | Selecon    | Balcony Bar       | Stage Right   |
| Address: 43  | #      | Channel | Type       | Position          | Use           |
|              | A-0355 | 43      | Selecon    | Balcony Bar       | Center Stage  |
| Address: 44  | #      | Channel | Type       | Position          | Use           |
|              | A-0357 | 44      | Selecon    | Balcony Bar       | Center Stage  |
| Address: 45  | #      | Channel | Type       | Position          | Use           |
|              | 45     | Selecon |            | Balcony Bar       | Stage Left    |
| Address: 46  | #      | Channel | Type       | Position          | Use           |
|              | 46     | SL23-50 |            | LX2               | Foleage Gobo  |
| Address: 49  | #      | Channel | Type       | Position          | Use           |
|              | A-0318 | 201     | Chauvet DJ | LX1               | Stage Right   |
| Address: 57  | #      | Channel | Type       | Position          | Use           |
|              | A-0319 | 202     | Chauvet DJ | LX1               | Center Stage  |
| Address: 65  | #      | Channel | Type       | Position          | Use           |
|              | A-0320 | 203     | Chauvet DJ | LX1               | Center Stage  |
| Address: 73  | #      | Channel | Type       | Position          | Use           |
|              | A-0321 | 204     | Chauvet DJ | LX1               | Stage Left    |
| Address: 81  | #      | Channel | Type       | Position          | Use           |
|              | A-0322 | 211     | Chauvet DJ | Balcony Bar       | Stage Right   |
| Address: 89  | #      | Channel | Type       | Position          | Use           |
|              | A-0323 | 212     | Chauvet DJ | Balcony Bar       | Center Stage  |
| Address: 97  | #      | Channel | Type       | Position          | Use           |
|              | A-0324 | 213     | Chauvet DJ | Balcony Bar       | Center Stage  |
| Address: 105 | #      | Channel | Type       | Position          | Use           |
|              | A-0325 | 214     | Chauvet DJ | Balcony Bar       | Stage Left    |
| Address: 113 | #      | Channel | Type       | Position          | Use           |
|              | A-0326 | 221     | Chauvet DJ | SR Under Balcony  | Under Balcony |
| Address: 121 | #      | Channel | Type       | Position          | Use           |
|              | A-0327 | 222     | Chauvet DJ | SL Under Balconyy | Under Balcony |
| Address: 129 | #      | Channel | Type       | Position          | Use           |
|              | A-0328 | 101     | Chauvet DJ | LX1               |               |
| Address: 144 | #      | Channel | Type       | Position          | Use           |
|              | A-0329 | 102     | Chauvet DJ | LX1               |               |
| Address: 159 | #      | Channel | Type       | Position          | Use           |
|              | A-0331 | 103     | Chauvet DJ | LX2               |               |
| Address: 174 | #      | Channel | Type       | Position          | Use           |
|              | A-0332 | 104     | Chauvet DJ | LX2               |               |

## Circuit: Balcony Power

| Channel    | Position         | #      | Type       |
|------------|------------------|--------|------------|
| 211        | Balcony Bar      | A-0322 | Chauvet DJ |
| 212        | Balcony Bar      | A-0323 | Chauvet DJ |
| 213        | Balcony Bar      | A-0324 | Chauvet DJ |
| 214        | Balcony Bar      | A-0325 | Chauvet DJ |
| 221        | SR Under Balcony | A-0326 | Chauvet DJ |
| 222        | SL Under Balcony | A-0327 | Chauvet DJ |
| Watts: 0.0 |                  |        |            |

## Circuit: Dimmer 1

| Channel       | Position          | #      | Type     |
|---------------|-------------------|--------|----------|
| 5             | Auditorium Circle |        | SL23-50  |
| 6             |                   |        | SL23-50  |
| 7             | LX1               | A-0350 | Selecon  |
| 8             | LX1               | A-0340 | par64mfl |
| 9             | LX1               | A-0351 | Selecon  |
| 10            | LX1               | A-0352 | Selecon  |
| 11            | LX1               | A-0341 | par64mfl |
| 12            | LX1               | A-0353 | Selecon  |
| 13            | SR Low            | A-0342 | Strand   |
| 14            | SR Low            | A-0343 | Strand   |
| 15            | SR Low            | A-0344 | Strand   |
| 16            | SR Low            | A-0345 | Strand   |
| 21            | SR Powered Bar    | A-0334 | par64mfl |
| Watts: 9350.0 |                   |        |          |

## Circuit: Dimmer 2

| Channel       | Position       | #      | Type     |
|---------------|----------------|--------|----------|
| 27            | SL Powered Bar | A-0338 | par64mfl |
| 31            | SL Low         | A-0346 | Strand   |
| 32            | SL Low         | A-0347 | Strand   |
| 33            | SL Low         | A-0348 | Strand   |
| 34            | SL Low         | A-0349 | Strand   |
| 41            | LX2            |        | SL23-50  |
| 42            | Balcony Bar    | A-0354 | Selecon  |
| 43            | Balcony Bar    | A-0355 | Selecon  |
| 44            | Balcony Bar    | A-0357 | Selecon  |
| 45            | Balcony Bar    |        | Selecon  |
| 46            | LX2            |        | SL23-50  |
| Watts: 7350.0 |                |        |          |

## Circuit: LED Power

| Channel    | Position | #      | Type       |
|------------|----------|--------|------------|
| 201        | LX1      | A-0318 | Chauvet DJ |
| 202        | LX1      | A-0319 | Chauvet DJ |
| 203        | LX1      | A-0320 | Chauvet DJ |
| 204        | LX1      | A-0321 | Chauvet DJ |
| Watts: 0.0 |          |        |            |

## Circuit: Mover Power

| Channel | Position | #      | Type       |
|---------|----------|--------|------------|
| 101     | LX1      | A-0328 | Chauvet DJ |
| 102     | LX1      | A-0329 | Chauvet DJ |
| 103     | LX2      | A-0331 | Chauvet DJ |
| 104     | LX2      | A-0332 | Chauvet DJ |